

INSTALLATION INSTRUCTIONS

358NDK DUCTLESS CONVERSION KIT FOR THRU SOFFIT VENTING FOR USE WITH PM250SSP POWER MODULE

1. Install PM250SSP per installation instructions shipped with power module.
2. Remove aluminum filter and attach the **CHARCOAL FILTER** (included) to the backside of the aluminum filter with the 4 supplied metal clips.
3. Cut hole in bottom of **SOFFIT** to allow clearance for the **90° ANGLE BOOT**.
4. Locate top of **4¼" X 10¼" OPENING** on soffit - centered on **POWER MODULE CENTERLINE** and **26.125"** above bottom of **POWER MODULE**.
5. Layout 4¼" x 10¼" pattern and cut opening in soffit.
6. Connect **90° ANGLE BOOT** to **7" ROUND DUCT**.
7. Insert boot end into soffit and connect 7" round duct end to the exhaust of the unit.
8. Install **GRILLE** (included - not shown) into soffit opening.
9. Use metal foil tape to make all connections secure and air tight.

