- 1. Clean area with Dicor Rubber Roof Cleaner
- 2. Measure damaged area and cut membrane at least 2 inches larger than the damaged area on all sides
- 3. Remove clear protective layer and place membrane over damaged area

Note: Do not try to cover large areas by butting 533RM-6 or 533RM-12 end-to-end or side-to-side (butt joints).

- 4. With small roller, apply pressure to flatten and make as smooth as possible
- 5. Remove beige protective layer and place a bead of Dicor Lap Sealant around edge