

This material is to be used on porous substrates only. Stir thoroughly before use and keep covered when not in use.

**Surface Preparation:** Clean, dry surfaces are required for optimum bond strength.

**Application Methods:** Apply adhesive evenly at a rate of one gallon for every 160-180 square feet to the substance by short nap roller.

**Open Time:** EPDM Rubber and TPO membranes should be immediately rolled onto the adhesive. No waiting time is necessary. Care should be taken to minimize the air trapped between substrates.

**Bonding:** Mate the surfaces with only enough pressure, evenly applied, to insure good contact between the substrates. Excessive pressure can redistribute the adhesive in an uneven manner.

**Empty containers:** When "empty" this package may contain harmful vapor and residue. Do not reuse container or remove labels. Follow label warning even "empty". Disposal should be in accordance with applicable regulations.

**Keep From Freezing.** Store products at 50° F to 60° F for maximum storage life. Do not store below 40° F.