

INSTALLATION

1. For best results, **The Original EZE GUTTER** should be installed when the outside temperature is at least 70°F and the gutter material is soft and pliable.
2. Use a small clean towel soaked with rubbing alcohol to clean the area where the material will be attached. Immediately wipe the alcohol-wet surface with a dry terry cloth towel before it dries. Replace dirty towels with clean ones as needed. Make sure all wax, dirt and polish have been removed.
3. Select a starting point and cut the gutter at an appropriate angle. In order to prevent water running down your side windows, it is suggested to install the gutter on the window frame and line the window on three sides, or at least as much as 6 to 8 inches long on each side to prevent gutter from coming loose on the ends. (Adds strength for best adhesion.)
4. Peel back the **3M** brand, red liner while pressing the gutter in place. Once the gutter is in place, it should not be repositioned. Never touch the acrylic foam tape with your hands.
5. Return to the starting point and, with the end of a toothbrush handle, rub the gutter channel back and forth. This creates heat for firm adhesion.

Important: Make sure you have enough material. Never pull or stretch the gutter during application.

Tools Needed:

- Rubbing alcohol (70% isopropyl)
- Anvil type pruning shears
- Toothbrush handle
- Utility knife
- Clear silicon (to fill small gaps) use sparingly.

When making guide lines use painter's tape or string.

Do not use chalk, pencil or pen.

Not recommended attaching to soft molding, painted or textured surfaces. In the case of a painted surface the gutter will adhere, however, we cannot be responsible if the gutter should have to be removed for any reason.

