

# Jack Spacer Kits: Kick-Down Jacks

**Application:** For spacing 6,000# and 9,000# jacks DOWN 1.5 INCHES.

**Mfr. #:** AP9434 Spacer Kit 1.5"

**Includes:** 2 - P9433 Spacer  
1 - AP9785 Hardware Kit

**Application:** For spacing 6,000# and 9,000# jacks DOWN 3 INCHES.

**Mfr. #:** AP9435 Spacer Kit 3.0"

**Includes:** 4 - P9433 Spacer  
1 - AP9786 Hardware Kit

**Application:** For spacing two 16,000# jacks DOWN 1.5 INCHES. (For use with above spacer)

**Mfr. #:** AP9787 Hardware Kit 1.5" Spacer, 16K

**Includes:** Hardware Only

