

Installation

It will be necessary to drill two 1/8" holes in the center louver to install the W-1000 screen.

NOTE: *use 1/8" shim between the louver slot to avoid crushing while drilling the holes.*

After drilling attachment holes install screen per instructions below.

1. Hold screen over water heater louver vent. Hook round end of spring to back of screen over anchor point.
2. Holding circle end of installation pin, push pin through screen and center of spring, place notch on center bar of lower spring coil, push hook toward anchor point.
3. Push spring hook past anchor point, turn, and release slowly to hook spring in back

Keep installation pin for future use

