



# MORryde ENTRY STEPS INSTALLATION INSTRUCTIONS

**NOTE:** MORryde is responsible for the design and manufacturing of our parts; we are not responsible for the structure it is mounted to. Improper installation may cause property damage or personal injury. MORryde cannot be liable for property damage or injury caused by incorrect mounting or incorrect use during travel or otherwise.

It is up to the installer to verify the safety of any installation method or hardware that is not provided by or recommended by MORryde.

**TOOLS NEEDED:** 3/8 drive socket

1. Before installation measure the distance from the ground to the bottom of the lip on the door sill. This should be between 39" - 41" for best fitment.
2. Next measure the space between the bottom of the door sill and the opening for the current steps. A distance of at least 1.75" is required to attach the steps. (Note: if there is any trim under the door sill the steps will not work).
3. Ensure that the mount brackets are on the step and fit the step up against the unit making sure that the mount brackets sit flush against the coach.
4. Adjust the step up or down so that there is approximately 1/4" space between the bottom of the door sill and the top of the step.
5. Center the step relative to the door.
6. Once the step is located properly, screw in the mount brackets using the supplied hardware (will need a 3/8 drive socket for the screws).
7. Press the paddle latches in and pull back to remove the step from the mount brackets. (Note: The paddle latches will need to be pressed in in order to remount the step after it has been removed).

