



Aqua-Magic® V Water Module Kit ua

ENGLISH

Needed

- Towel(s)
 Trash bag
 Pliers
- · Cutting Tool (if Water Saver present)

Note - We strongly recommend you:

- Read all instructions completely before starting.
- Reduce holding tank odor: Rinse toilet with at least 1 gallon of water. Drain Holding Tank. Add appropriate dose of Thetford Holding Tank Deodorant.

To Uninstall Toilet

- Turn off RV water supply per RV Owner's Manual.
- 2. Drain water from Toilet by actuating flush.
- Place towel(s) behind Toilet under water connection to catch spill when disconnecting.
- 4. Disconnect water supply line from Water Module. (Different vehicle manufacturers route water supply lines differently, so you must determine the best method.)
- 5. Remove Closet Flange Bolt Covers, if present, and Nuts.
- Lift Toilet off floor and place upside down on trash bag with back facing you.
- 7. Cover Holding Tank opening.
- 8. Remove old Closet Flange Seal. Discard.

To Repair Toilet

If your model has the optional Water Saver Hand Spray installed, disconnect it now:

- 1. Loosen Clamp; slide Clamp down hose.
- 2. Pull Hose off Barb to free Hand Spray and set aside.

- 1. Flip toilet to right side up.
- 2. Remove Retaining Screw (Fig. A).
- 3. Twist/pull Flush Tube off the Hose Barb of Water Module.
- Lift Water Module locking Tab to release Water Module (Fig. A). Pull the module out of groove.
- Angle Water Module to disconnect its Link from Lever Arm hole (Fig. B). (On Hand Flush models, Lever Arm includes Flush Handle, shown in lighter gray.) Discard Water Module and Link.
- Connect new Water Module link to Lever Arm hole.
- Position new module as shown in Fig. A. (To allow the slide to line up with the groove, pull slightly on Lever Arm.) Slide Module in to groove and lock into place.
- Attach Flush Tube to Hose Barb. It will slide over internal seal and snap into place.
- 9. Replace Retaining Screw. Tighten.

To Reinstall Toilet

If your model has the optional Water Saver Hand Spray, reconnect it now:

- 1. Locate Hose Barb and cut off its bottom tip evenly at lowest rib.
- Push Hose firmly onto Hose Barb; reposition Clamp over Hose Barb and secure.
- 1. Turn Toilet upside down.
- 2. Install new Closet Flange Seal, lip side up, on Toilet (Fig. C).
- 3. Uncover Holding Tank opening. Remove water spill towel(s).
- 4. Replace Toilet on floor, aligning mounting holes with Closet Bolts.
- 5. Tighten Closet Flange Nuts until Toilet doesn't rock. Do not overtighten. Replace Bolt Covers
- 6. Reattach water supply line.
- 7. Turn on RV water supply per RV Owner's Manual.
- 8. Flush test toilet, checking for leaks at all connections.



