

## WALL CAP

The Wall Cap is designed for use with 3" or 4" round duct.



**Do not use for dryer venting.**

## INSTALLATION

The Wall Cap consists of two (2) sections: the cap assembly and the 3" to 4" round transition.

When 3" duct is used, install reducer as illustrated.

Attach Wall Cap to the outside wall with screws through the provided holes in flange.

