



Scissor Step Mounting Instructions

Product No.: AS02, AS03, AS04, AS05, AS23, AS24, AS25, SS02, SS03, SS04

Congratulations! You have chosen a high quality scissor stair that has been carefully manufactured to rigid production specifications. With very little maintenance, this stair will last a long time.

Installation:

1. Open stair to length that optimizes level position of steps when mounted and slip mounting bracket on the upper (shorter) bar. Position against camper for best access to door opening. Block stair in place.
2. With stair blocked in desired position, open and close camper door to assure the mounting position will allow free movement of door.

We recommend a minimum of 1/8" clearance be maintained between the lowest point of the door and the mounting bracket.

Note: These stairs are available in either aluminum or steel and in a two, three or four step configuration. Refer to chart below to determine the size that is correct for your application:

<u>Product #</u>	<u>Vertical Extension</u>
AS02/SS02	18" - 23"
AS03/AS23/SS03	24" - 30"
AS04/AS24/SS04	31" - 39"
AS05/AS25	40" - 48"

3. With stair in place and positioned for best access, mark the holes with a scribe or felt pen. Remove stair and drill with a 5/32" drill bit. Minimum depth: 1 1/4". Maximum depth: 1 3/4".

Note: be sure there are no electrical wires, water lines or anything else in the path of the drill bit before you drill.

4. Secure the mounting bracket in place with the four (4) 1/4" x 1 1/2" long lag screws. Note that the mounting bracket included with scissor stairs # AS23, AS24 and AS25 has five (5) holes. The middle hole on that mounting bracket does *not* require a lag screw.

Notes: Be sure stairs are mounted in both "V" carriers on mounting bracket before using the stairs. It is important to extend the stair until it reaches the stop pins on the bottom bars. Failure to do so may cause stairs to fold up while in use. Remove stair for travel.

WARNING: This step is only to be used while vehicle is stationary. Do not permanently mount step. Use mounting bracket provided so step is easily removed prior to vehicle travel. If step is not removed prior to travel, injury and damage may occur and voids warranty and liability.

