



Instructions

Tools Required: Screwdriver

- Turn off water supply. Remove old handle
 by prying off index button (A), removing screw (B) and pulling off handle (C).
- 2. Remove old flange (D) by unthreading. Remove old flange nipple (E) by unthreading.
- 3. Install new nipple by threading tapered end into bonnet nut (F). It may be necessary to shorten new nipple but this can easily be done with a saw.
- 4. Install new flange (D) by threading onto nipple (E) and tightening to wall.
- 5. Place new handle (C) on faucet stem, then tighten with new handle screw (B).
- 6. Replace index button (A) and turn on water supply to faucet.