

*Equity*<sup>®</sup>

# QUARTZ ALARM CLOCK

OPERATING INSTRUCTIONS MODEL# 27001/27002/27006

## To START CLOCK

1. Remove the battery cover from the back of the clock.
2. Insert one (1) "AA" battery (not included) according to the polarity indicators (+/-) inside the battery compartment. Replace the battery cover.

## To SET TIME:

Turn the time set knob at the back of clock clockwise to the desired time.

## To SET ALARM:

1. Turn the alarm set knob at the back of the clock counterclockwise to desired alarm time.
2. Slide the alarm switch to the "ON" position.
3. When the alarm sounds, slide the alarm switch to the "OFF" position to deactivate the alarm.

## SNOOZE & LIGHT OPERATION:

1. Press the button on the front side of the clock case to activate the snooze and light.
2. The alarm will sound again in 5 minutes.

## NOTE:

This clock should be accurate to within a few minutes a year. Should the timekeeping suddenly fluctuate replace the battery.

**Always purchase the correct size and grade of battery most suitable for the intended use. Clean the battery contacts and also those of the device prior to battery installation. Ensure the battery is installed correctly with regard to polarity (+and-). Remove used battery from equipment when it is not to be used for an extended period of time. Remove used battery promptly. Please help in preservation of the environment and return used battery to an authorized depot. Replace all batteries of a set at the same time.**

