

» **Protection button, what does it do?**

Jun 30, 2016

The protection button comes in the engaged position which allows output to the speakers. If a short were to occur on the output stage that button will act as breaker and pop in the out position to let you know there is a problem it will cut off all sound when this occurs. At that time you need to trace which output has the short and push in the button again before it can be used