

RA-25 & RA-25K Lock'em Magnum Wheel Lock

You have just purchased the Lock'em Magnum Wheel Lock by Rack'em. This high quality maximum strength lock will immobilize automobiles, SUVs, trucks, motorcycles, utility trailers, boat trailers, construction and landscape equipment. Etc... practically anything with wheels.

INSTRUCTIONS FOR USE:

Your Lock'em Magnum Wheel Lock key is needed to unlock the unit, but is not needed to lock it. Your RA-25/RA25K small side will fit tire sizes: 12", 13", 14", & 15". The large side will fit tire sizes: 15", 16", 17", 18" 19" & 20". **PLEASE NOTE THIS LOCK WILL NOT FIT 20"X20"X10" LOW PROFILE TIRES.** Consult the sizing sticker on the unit to determine which side will work best and choose the side that fits best for the particular wheel you are locking. Put the arms around the wheel and slide the lock together until it won't go any further. The clicking sound is the lock mechanism engaging. The arms are rubber coated to prevent damage. The locking procedure is the same for trailers, cars, equipment, etc... To unlock your Lock'em Magnum wheel lock insert key and turn it then slide the unit apart. Make sure to always install your lock with the key hole towards the outside to ease installation and removal. Lock the 2 halves together for storage.

WARNING:

You must remove your Lock'em Magnum wheel lock from all wheels before driving or moving any vehicle or equipment. If you fail to do so, serious damage to the vehicle or equipment can result. Rack'em Manufacturing LLC. will not be held liable for any damage that may occur due to negligence or failure of the owner, driver, or any operator to use the wheel lock as directed. This includes, but is not limited to failure to remove the lock from wheel before moving vehicle or equipment.

Exercise extreme caution when using your Lock'em Magnum wheel lock on a vehicle or equipment so as not to put yourself in the path of traffic. Using the Lock'em Magnum wheel lock on the front driver side wheel will make it easier to install and act as a visual reminder to remove the lock prior to driving or moving the vehicle or equipment. For safety it can be installed on the passenger side.

More than 1 lock can be used for extra security. Make sure to always install your Lock'em Magnum wheel lock with the key cylinder towards the outside to ease the installation and removal. It can also be used on some steering wheels. The key number is only on the red tag that comes with the keys and on the key itself, so record your key number and keep it in a safe place, so in case you misplace or lose the keys you can order a set of replacement keys.

NOTE: It is the buyer's sole responsibility to make sure that the wheel lock is installed safely and securely the vehicle wheel.