

RV BUG SCREEN (A10-1313VP)

PARE-INSECTES POUR VR



For Dometic® RV refrigerators with 6 vents

- Open refrigerator vent door.
- Working from the outside of the door, position the vents screens over the door vents (figure 1). Trim the screen with wire cutters or snips if needed. The screens should cover the entire vent opening.
- Attach each of the 6 screens to the center bar of each vent with two of the provided P-ties. Trim excess P-tie material.

Cleaning the screens is necessary for proper air flow. Inspect screens frequently and clean as needed.

Figure 1

Insert screens from OUTSIDE of vent door.

