LA CROSSE® TECHNOLOGY

16" Atomic Wall Clock




Model: WT-3161WH DC: 062617

Power up

- 1. Select Time Zone and DST ON or OFF.
- 2. Insert 1 AA battery into the movement.
- 3. For best reception, place clock on a wall that faces Ft. Collins, Colorado.
- 4. During the night, your clock will set itself.

IMPORTANT:

- Hands will move to 12:00 and search for the atomic time signal.
- If no signal, after 8-10 minutes, clock will run from 12:00 am.
- Clock will continue to search for the WWVB atomic time signal.
- Allow up to 5 nights for the clock to receive the atomic time signal.






) WAVE (Atomic search)

- 3 RESET
- (4) Battery

5) Time Zone Selector



Care and Maintenance

- Always purchase the correct size and grade of battery most suitable for use.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the battery is installed with correct polarity (+ and -).
- Remove battery from equipment which is not to be used for an extended period of time.
- Promptly remove an expired battery.

Set the clock manually:

- 1. Hold SET for 3 seconds
- 2. Press and Hold **SET** to move hands quickly.
- 3. Press and release **SET** to move hands forward step by step.
- 4. The atomic time signal will override manual settings.

Reset:

If the clock does not respond to function modes, press the RESET button on the movement case.

Specifications

Batteries: 1 AA (IEC LR6) required in movement (Alkaline recommended) Battery Life: over 12 months with reputable battery brand