DAP® Alex Plus® Spackling

PRODUCT DESCRIPTION

DAP® ALEX PLUS® Spackling is a premium spackling for filling holes and cracks in surfaces such as drywall, plaster, wood, brick, metal and stone. It's ready-to-use smooth, white formula spreads easily for fast, professional repairs that will not crack, crumble or flake. It has a de-aired texture for excellent tooling and easy smoothing to a feather edge. Alex Plus Spackling sands effortlessly. It can even be finger sanded – no sandpaper needed when sanding small nail holes or hammer dents in drywall. Just use finger to smooth dried spackling before painting. Alex Plus Spackling provides superior paint-ability. It does not flash or gloss low sheen/flat paint. It accepts paint like bare drywall or other porous surfaces and provides a very smooth surface that disappears when painted. Alex Plus Spackling dries quickly but has a long working time and will not gum up on knife. It can be used for interior or exterior applications.



PACKAGING	COLOR	UPC
7 oz. (236 mL) Tube	White	7079818744
16 fl oz	White	7079818745
32 fl oz	White	7079818746
128 fl oz	White	7079818797
Half Pint Kit	White	7079818795

KEY FEATURES & BENEFITS

- Professional Strength Repairs
- Fill in One Coat Won't Sink or Shrink
- Superior Paint-ability Won't Flash Paint
- Exceptional Durability
- Interior/Exterior use



SUGGESTED USES

Ideal for filling holes, cracks, dents and defects on:

- Drywall
- Wood
- Brick

- Stone
- Metal Doors & Trim

FOR BEST RESULTS

- Do not apply when temperatures are below 50°F.
- Do not apply outside if rain is expected within 24 hours.
- Do not use on floors or as a caulk, sealant or joint filler over cracks and joints where expansion and contraction may occur.
- DO NOT USE AS A SKIM COAT.
- For exterior applications, always topcoat with a quality paint.
- If a textured finish is desired, add clean sand to spackling compound prior to application.
- Do not use for tuck pointing applications on brick.
- For larger areas to be patched on bare concrete, use a latex fortified Portland cement-based dry mix.

APPLICATION

- 1. Surface must be clean, dry and free of foreign material.
- 2. Stir thoroughly before use. If using squeeze tube, knead tube before use and cut nozzle to desired opening size.
- 3. Apply with a clean putty knife.
- 4. For a smoother finish, dip putty knife in water and lightly smooth spackling.
- 5. One application is usually sufficient for small repairs. For repairs deeper than 1/8", apply two or more layers allowing spackling to dry between applications.
- 6. May be sanded or painted in 1 to 5 hours depending on temperature, humidity and depth of fill. Wet sanding is recommended to avoid generation of dust.
- 7. Clean tools immediately with water.
- 8. Ensure that ALEX PLUS Spackling is thoroughly dry before sanding or applying oil-based paint. Spackling may be painted immediately upon drying with a quality latex paint.

TYPICAL PHYSICAL & CHEMICAL PROPERTIES

Consistency	Paste	
Vehicle	Latex Polymer	
Volatile	Water	
Filler	Inert Filler	
Odor	Mild	
Weight/Gallon	15.6 pounds	
Solids	76% by weight	
Application Temperature	50°F or higher	
Service Temperature	0°F to 150°F	
Shelf Life	12 months	
Freezing	Freeze/thaw stable 5 cycles at 0°F	
Dry Time	1 to 5 hours depending on temperature, humidity and depth of fill	

CLEAN UP & STORAGE

- · Wash tools immediately after use with water.
- Dried material must be removed by scraping or sanding.
- Be sure container lid/cap is closed and tightly sealed.
- Store in a cool, dry place.

• How To's/Tips

For a Smoother Finish

For a smoother finish, dip putty knife into water & lightly smooth spackling prior to drying.

Achieve a Smooth Finished Repair

Dual-grit sanding using medium (60 to 100-grit) and finishing with fine (120 to 220-grit) sandpaper will help achieve a smooth finished repair.

Best Application Experience

Using a flexible putty knife will provide the best application experience when applying spackling compound.

Better Adhesion to Drywall

De-gloss surface with sandpaper for better adhesion to the drywall.

Overfill the Repair Slightly

Overfill the repair slightly when applying so you can sand it down to a smooth, flat finish when dry.

Create a Smooth Surface

Use the back of a putty knife to knock down any rough edges of the repair to create a smooth surface.